

DATE												
TIME												
ENGINE HOURS												
REVS												
Check fuel manifold levers in correct position	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐
Gals in day tank												
Gals in port tank												
Scan for loose items	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐
Note abnormal smells or sounds	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐
Check main engine thermostat housing (183)												
Check alternator temp (100-140)												
Check Hydraulic pump impellor temp (50-100)												
Check Hydraulic reservoir temp (80-110)												
Check Transmission temp (110-180)												
Check Engine room temp (MAX 135)												
Check Shaft seal temp (90-125)												
Check for drip under shaft	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐
Check Main engine fan belts - secure	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐
Check hoses and clamps for leaks	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐
Check STBD side engine for fuel or oil leaks	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐
Check Bilge water level under PTO	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐
Check stabilizer oil level	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐
Check hydraulic fluid level	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐
Check AFT Generator belts, fuel and oil leaks	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐
Check FWD Generator belts, fuel and oil leaks	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐
Check Tool box is locked	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐
Check Port side main engine for fuel or oil leaks	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐
Check Port side main engine wires condition	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐

Tick boxes when checked OK. Type readings (temps, gallons, levels) in the white cells.

Notes